

EMERGENCY STOP SWITCH COVERS

Emergency Stop Switch Covers protects and prolongs the life of the switch.

- » **SILICON RUBBER COVER WITH ALUMINIUM FITTING**
- » **REDUCES DIRT & MOISTURE PENETRATION**
- » **PROLONGS THE LIFE OF THE SWITCH**
- » **REDUCES MACHINE DOWNTIME**



TO SUIT SCHNEIDER XALK174

PART NO. NPR1822

TO SUIT SCHNEIDER XAPM1316H29

PART NO. NPR2053